

重点校对项

1. 物料编码

2. 版面尺寸

3. 材质标注

4. 颜色标注

5. 客户型号

6. 产品名称

7. 产品参数

8. 电压功率

9. 单位符号

10. 认证标志

11. 回型标志

12. ROHS标志

13. 警语警语及字高

14. 控制面板及功能

15. 目录及页码

16. 商标LOGO

标准元素核对表 (此表仅用于印刷品制作过程核对标准内容, 非印刷内容)

认证图标	<p>大于5mm 大于5mm 大于5mm 大于5mm 大于7mm ETL有C或US或C+US UL只有C+US或无 GS图标无高度要求, 印刷可见即可 说明书、保修卡类</p>
单位表述	直流电: V= 交流电: V- 频率: Hz 功率: W 容量: mL/L 电流: A 压强: Pa/kPa/MPa 长度: mm/cm/m 时间: s/min/h 重量: kg
产地表述	MADE IN CHINA Made in China Made in P.R.C
变更要求	图纸变更需要核实变更内容点以及涉及的物料和MO单, 尤其关注92的在途MO单



USER MANUAL  
MRD100T1BDG

Warning notices: Before using this product, please read this manual carefully and keep it for future reference. The design and specifications are subject to change without prior notice for product improvement. Consult with your dealer or manufacturer for details. The diagram above is just for reference. Please take the appearance of the actual product as the standard.

技术要求 (版本号: B, 2023-06)

- 文字图案印刷颜色为: 黑色, 印刷字体需清晰可见, 文字不能粘到一起;
- 该说明书的幅面大小为: A5, 未注直线尺寸公差应符合GB/T1804-v;
- 该说明书的装订方式为: 钉装; [70P以下为钉装, 70P以上为胶装 (特殊要求除外)]
- 说明书警语及认证标志应满足CE/UL标准, CE: 警语部分大写字母高度不低于3mm, CE标志不低于5mm, WEEE标志不低于7mm; UL: 大写字母字高不小于1/12" (2.11mm), 小写字母字高不小于1/16" (1.6mm), "IMPORTANT SAFEGUARDS", "SAVE THESE INSTRUCTIONS" 等词, 其字高不小于3/16" (4.8mm), IMPORTANT SAFEGUARDS 必须在最前面。
- 产品应符合QMG-J53.021《产品说明书技术条件》的有关要求。
- 有ROHS指令要求的物料应符合美的的企业标准QML-J11.006《产品中限制使用有害物质的技术标准》。

				电饭煲		编码 22061070001181	
				说明书		MB-RC350W-0501	
A0: 功能描述修订频率与铭牌保持一致-麦影涛-20240413						材料: 80g双胶纸	
标记处数	更改文件号	签字	日期	图样标记	重量	比例	
制图	麦影涛	审核	卢灿飞	K		1:1	
设计	-----	标准化	古广君				
校对	陈福贞	审定	古广君				
会签	-----	日期	2024-02-20	共 1 页	第 1 页		

广东美的生活电器制造有限公司



**RICE COOKER**

# **USER MANUAL**

**MRD100T1BDG**

Warning notices: Before using this product, please read this manual carefully and keep it for future reference. The design and specifications are subject to change without prior notice for product improvement. Consult with your dealer or manufacturer for details.

The diagram above is just for reference. Please take the appearance of the actual product as the standard.

## THANK YOU LETTER

Thank you for choosing Midea! Before using your new Midea product, please read this manual thoroughly to ensure that you know how to operate the features and functions that your new appliance offers in a safe way.

# CONTENTS







<b>THANK YOU LETTER</b>	01
<b>SAFETY INSTRUCTIONS</b>	02
<b>SPECIFICATIONS</b>	08
<b>PRODUCT OVERVIEW</b>	09
<b>OPERATION INSTRUCTIONS</b>	10
<b>CLEANING AND MAINTENANCE</b>	24
<b>TROUBLESHOOTING</b>	25
<b>TRADEMARKS, COPYRIGHTS AND LEGAL STATEMENT</b>	27
<b>DATA PROTECTION NOTICE</b>	28

# SAFETY INSTRUCTIONS

## Intended Use

The following safety guidelines are intended to prevent unforeseen risks or damage from unsafe or incorrect operation of the appliance. Please check the packaging and appliance on arrival to make sure everything is intact to ensure safe operation. If you find any damage, please contact the retailer or dealer. Please note modifications or alterations to the appliance are not allowed for your safety concern. Unintended use may cause hazards and loss of warranty claims.

## Explanation of Symbols

	<b>Danger</b> This symbol indicates that there are dangers to the life and health of persons due to extremely flammable gas.
	<b>Warning of electrical voltage</b> This symbol indicates that there is a danger to life and health of persons due to voltage.
	<b>Warning</b> The signal word indicates a hazard with a medium level of risk which, if not avoided, may result in death or serious injury.
	<b>Caution</b> The signal word indicates a hazard with a low degree of risk which, if not avoided, may result in minor or moderate injury.
	<b>Attention</b> The signal word indicates important information (e.g. damage to property), but not danger.
	<b>Observe instructions</b> This symbol indicates that a service technician should only operate and maintain this appliance in accordance with the operating instructions.

Read these operating instructions carefully and attentively before using/commissioning the unit and keep them in the immediate vicinity of the installation site or unit for later use!

# SAVE THESE INSTRUCTIONS

## CAUTION

- Read Rules for Safe Operation and Instructions Carefully.
- This electric cooker can only be heated with the original inner pot. For products with metal steamer, the steamer can not be used as a separate container to avoid overheating, plastic melting or even fire.
- Do not drop the inner pot, and do not use hard objects to hit against the inner pot to avoid deformation. A deformed inner pot must be replaced.
- To avoid high temperature burns, do not directly touch the inner pot and heating plate (coil plate) with your hands during operating or just after use.
- Improper repair or short-circuiting without permission of some important accessories including fuse may lead to protection failure of the appliance and cause overheating or fire.
- When the appliance is used by persons with cardiac pacemakers or implanted cochlearly, please consult the authorized medical personnel and refer to the instructions of the medical device provider.
- Any discrepancy between the picture and the product is subject to the real object.
- Before operation, check whether the cooking pot and steam valve are in place to avoid accident.
- During use, it is normal that the appliance slightly ticks or fizzes. Please do not panic.
- Please do not cook again immediately after cooking. You shall wait for more than 15 minutes after stopping so that the heating plate (coil plate) can cool down.

- For products with hot water cooking function, please follow the instructions in the Quick Start Guide; do not cook with hot water for products without hot water cooking function, otherwise the temperature judgement of the thermostat will be affected, resulting in poor cooking effect.
- Please clean and check the steam valve and movable cover regularly. Please also clean and check the countertop regularly where the product is placed.
- The altitude scope for the appliance to properly function is 0~2000 m.
- In order to ensure the best result achieved, led when cooking more than 4 cups of rice, do not use steamer to steam food.
- Under indoor circumstance of insufficient grounding device, sensitive individuals may feel faradism. We recommend you to check whether grounding device is reliable, or never touch metal housing and inner cooking pot.
- Before using the rice cooker, please clear the water, rice and other foreign objects appears in between inner pot and heating coil to avoid overheating or in short circuit.
- Before using the electric cooker, it is necessary to wipe dry the exterior of the inner pot to avoid malfunction.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

## **⚠ WARNING**

- During operation, do not cover the steam valve with cloth, and placing the product near flammable materials is strictly prohibited. When using the product, keep it away from window curtains, drapes, door curtains or similar materials to prevent causing a fire.
- Do not use this pot to make food that is easy to block the vent, such as flaky food (such as laver and cabbage) or banded food (such as kelp) and fragmented food (such as corn grits), so as not to cause accidents or damage to rice cookers.
- During operation, do not place your hands or face close to the steam vent to avoid burns.
- Do not reform the appliance: only the maintenance personnel are allowed to disassemble or repair it in case of the fire, electric shock or injury.
- Do not use the appliance on any voltage except for 220-240V AC to avoid the risk of fire and electric shock. In case of power wire damage, do not use the appliance.
- Do not operate the appliance in the following ways to avoid fire risk and electric shock due to power line damage: Forcibly bend the power cord, keep it close to high-temperature objects, tie up the line or use it to carry weights.
- In case of power plug damage, do not use the appliance to avoid the risk of fire, electric shock and short circuit. If the power line is too short, user should use an extension socket for. Please do not use poor-quality socket.
- Do not pull the plug with wet hands to avoid electric shock and injury to persons.
- During operation, do not move or shake the appliance.

- Keep the appliance out of the reach of unsupervised children and babies to avoid dangerous accidents such as electric shock and burns.
- Do not put the appliance in unsteady, damp places or close to other fire and heat sources (e.g. stove). The optimum distance is 30 cm. Otherwise, damage or accident may happen to the appliance.
- Do not insert pin, iron wire or other articles into the steam vent at the bottom of the appliance to avoid electric shock and injury to persons.
- Don't immerse the appliance in water or drench with water.
- Independently use grounding socket with rated current of above 10 A. When used with Others electrical appliances, the socket will go wrong and lead to dangers such as fire disaster.
- Clean the dust and water on both ends of the power line and the socket of the appliance to avoid the risk of fire, electric shock and short circuit.
- When maintenance or parts replacement is necessary, please deliver the product to the authorized professional service centre for maintenance of Midea. To avoid hidden dangers caused by improper maintenance or improper selection of accessories.
- The plug should be thoroughly inserted into the socket to avoid the risk of fire, electric shock and short circuit.
- For type X connectors: If the power cord is damaged, it must be replaced with a dedicated cord or with a dedicated component purchased from the manufacturer or maintenance department. For type Y connectors: In case of supply cord damage, the cord should be replaced by professionals of the Manufacturer, the Maintenance Department or similar departments.




- The appliance is for household use only.
- Do not use the appliance when connected to a timer or an independent remote control system.
- During the operation of the appliance, certain surface may become hot and cause high temperature. Please pay attention to these areas to avoid burns. Do not touch the hot plate and the product surface by hand.

# SPECIFICATIONS

<b>Product Model</b>	<b>MRD100T1BDG</b>
Voltage	220-240V~
Frequency	50/60Hz
Power	605-720W
Capacity	1.0L

# PRODUCT OVERVIEW

## Component Name



## Parts List



Standing rice spoon



Measurement cup



Manual



Power cord




Steamer

### NOTE

All the pictures in this manual are for explanation purpose only. Any discrepancy between the real object and the illustration in the drawing shall be subject to the real subject. Remove parts from the component before performing installation.

# OPERATION INSTRUCTIONS

## Operation Part



### NOTE


Sleep Sate, the product automatically enters sleep state if there is no operation in 5 minutes, the nixie tube displays [- -], and all other indicator lights turn off. In sleep state, you can press any key to exit the state.

## Instructions for Use

### Rice-water Ratio


#### 1. Rice measuring method

1 measuring cup of rice can be cooked into 2 bowls of steamed rice, and the diameter of the bowl is about 11.5 cm.



#### 2. Put in the rice and water

Take cooking 2 cups of rice as an example, put the washed rice into the inner pot and add water to the corresponding scale line 2 (the water level line shall be subject to the actual object)




## Function Description

(For specific functions, please refer to the actual panel for selective reference)

### JASMINE RICE

1. Using the included measuring cup, add the uncooked rice to be cooked into the inner pot.
2. Wash the rice, remove excess starch, and pour away the water; repeat this at least 2 times until the rice washing water becomes
3. Add appropriate amount of water according to the amount of uncooked rice to be cooked (refer to the water level of Jasmine Rice in the inner pot).
4. Wipe the moisture on the outer surface of the inner pot and place the inner pot into the cooker. Make sure that there are no foreign objects on the bottom where the cooker is in contact with the inner pot, and then close the lid.
5. Plug the power cord into an available power outlet (220-240V~ 50/60Hz).
6. Press the "MENU" key, select the "JASMINE RICE" function and then press the "START" key to start cooking.
7. The cooker beeps, a rotating light symbol appears on the nixie tube, and the cooker starts cooking.
8. After cooking is completed, the cooker will beep and automatically enter the keep-warm mode.
9. Open the lid and stir the rice using the included rice spatula to expel any remaining moisture and make the rice more perfect.
10. After taking out all the rice, unplug the power cord of the cooker.




### NOTE

1. The amount of rice and water used for cooking must not exceed the maximum water level of the inner pot.
2. Users can also adjust the ratio of rice to water for cooking according to their own needs.
3. Do not leave rice in the appliance to keep it warm for more than 12 hours.

## BROWN RICE

1. Using the included measuring cup, add the uncooked rice to be cooked into the inner pot.
2. Wash the rice, remove excess starch, and pour away the water; repeat this at least 2 times until the rice washing water becomes
3. Add appropriate amount of water according to the amount of uncooked rice to be cooked (refer to the water level of Jasmine Rice in the inner pot).
4. Wipe the moisture on the outer surface of the inner pot and place the inner pot into the cooker. Make sure that there are no foreign objects on the bottom where the cooker is in contact with the inner pot, and then close the lid.
5. Plug the power cord into an available power outlet (220-240V~ 50/60Hz).
6. Press the “MENU” key, select the “BROWN RICE” function and then press the “START” key to start cooking.
7. The cooker beeps, a rotating light symbol appears on the nixie tube, and the cooker starts cooking.
8. After cooking is completed, the cooker will beep and automatically enter the keep-warm mode.
9. Open the lid and stir the rice using the included rice spatula to expel any remaining moisture and make the rice more perfect.
10. After taking out all the rice, unplug the power cord of the cooker.




### NOTE

1. The amount of rice and water used for cooking must not exceed the maximum water level of the inner pot.
2. Users can also adjust the ratio of rice to water for cooking according to their own needs.
3. Do not leave rice in the appliance to keep it warm for more than 12 hours.

## MIXED RICE

1. Using the included measuring cup, put the mixed rice to be cooked into a basin and soak in hot water for 2-3 hours.
2. Add the soaked mixed rice to the inner pot.
3. Wash mixed rice, remove excess starch, and pour away the water; repeat this operation at least 2 times until the rice washing water becomes clear.
4. Add appropriate amount of water according to the amount of mixed rice to be cooked (refer to the water level of Jasmine Rice in the inner pot).
5. Wipe the moisture on the outer surface of the inner pot and place the inner pot into the cooker. Make sure that there are no foreign objects on the bottom where the cooker is in contact with the inner pot, and then close the lid.
6. Plug the power cord into an available power outlet (220-240V~ 50/60Hz).
7. Press the “MENU” key, select the “MIXED RICE” function and then press the “START” key to start cooking.
8. The cooker beeps, a rotating light symbol appears on the nixie tube, and the cooker starts cooking.
9. After cooking is completed, the cooker will beep and automatically enter the keep-warm mode.
10. Open the lid and stir the rice using the included rice spatula to expel any remaining moisture and make the rice more perfect.
11. After taking out all the mixed rice, unplug the power cord of the cooker.




### NOTE

1. The amount of rice and water used for cooking must not exceed the maximum water level of the inner pot.
2. Users can also adjust the ratio of rice to water for cooking according to their own needs.
3. Do not leave mixed rice in the appliance to keep it warm for more than 12 hours.

## CRISPY RICE

1. Using the included measuring cup, add the uncooked rice to be cooked into the inner pot.
2. Wash the rice, remove excess starch, and pour away the water; repeat this at least 2 times until the rice washing water becomes
3. Add appropriate amount of water according to the amount of uncooked rice to be cooked (refer to the water level of Jasmine Rice in the inner pot).
4. Then add an appropriate amount of oil and salt (it is recommended to add 30g oil and 2g salt per cup of rice), and stir evenly.
5. Wipe the moisture on the outer surface of the inner pot and place the inner pot into the cooker. Make sure that there are no foreign objects on the bottom where the cooker is in contact with the inner pot, and then close the lid.
6. Plug the power cord into an available power outlet (220-240V~ 50/60Hz).
7. Press the "MENU" key, select the "CRISPY RICE" function and then press the "START" key to start cooking.
8. The cooker beeps, a rotating light symbol appears on the nixie tube, and the cooker starts cooking.
9. After cooking is completed, the cooker will beep and automatically enter the keep-warm mode.
10. Open the lid and stir the rice using the included rice spatula to expel any remaining moisture and make the rice more perfect.
11. After taking out all the rice, unplug the power cord of the cooker.




### NOTE

1. The maximum amount of rice supported by CRISPY RICE is 3 cups.
2. Users can also adjust the ratio of rice to water and oil and salt for cooking according to their own needs.
3. Do not leave crispy rice in the appliance to keep it warm for more than 12 hours.



## CONGEE

1. Using the included measuring cup, add the uncooked rice to be cooked into the inner pot.
2. Wash the rice, remove excess starch, and pour away the water; repeat this at least 2 times until the rice washing water becomes clear.
3. Add appropriate amount of water according to the amount of uncooked rice to be cooked (refer to the water level of Congee in the inner pot).
4. Wipe the moisture on the outer surface of the inner pot and place the inner pot into the cooker. Make sure that there are no foreign objects on the bottom where the cooker is in contact with the inner pot, and then close the lid.
5. Plug the power cord into an available power outlet (220-240V~ 50/60Hz).
6. Press the “MENU” key, select the “CONGEE” function (default is 1:30; press “+” “-” to adjust in the range of 1:00-2:00) and then press the “START” key to start cooking.
7. The cooker beeps, a rotating light symbol appears on the nixie tube, and the cooker starts cooking.
8. After cooking is completed, the cooker will beep and automatically enter the keep-warm mode.
9. When opening the lid, be careful to avoid escaping steam, then use a rice spatula to stir evenly.
10. After taking out all the congee, unplug the power cord of the cooker.




### NOTE

1. The “+” “-” keys support short pressing (the step is 0:10) and continuous pressing (the step is 0:10).
2. The amount of rice and water used for cooking must not exceed the maximum water level of the inner pot.
3. Users can also adjust the ratio of rice to water for cooking according to their own needs.
4. Do not leave congee in the appliance to keep it warm for more than 12 hours.

## STEAM

1. Add water to the inner pot according to the STEAM water level of the inner pot.
2. Wipe the moisture on the outer surface of the inner pot and place the inner pot into the cooker. Make sure that there are no foreign objects on the bottom where the cooker is in contact with the inner pot.
3. Put the food to be steamed into the included steamer.
4. Put the steamer into the inner pot and close the lid.
5. Plug the power cord into an available power outlet (220-240V~ 50/60Hz).
6. Press the "MENU" key, select the "STEAM" function (default is 0:30; press "+" "-" to adjust in the range of 0:01-1:00) and then press the "START" key to start cooking.
7. The cooker beeps, a rotating light symbol appears on the nixie tube, and the cooker starts cooking.
8. After cooking is completed, the cooker will beep and automatically enter the keep-warm mode.
9. When opening the lid, be careful to avoid escaping steam and then check the cooked food for doneness.
10. After cooking, please take out the food carefully to avoid over-cooking, and be careful when taking out the food to avoid burns.
11. After taking out all the cooked food, unplug the power cord of the cooker.




## NOTE

1. The "+" "-" keys support short pressing (the step is 0:01) and continuous pressing (the step is 0:10).
2. Do not leave the food in the appliance to keep it warm for more than 12 hours.

## SOUP

1. Add ingredients to the inner pot and add appropriate water as needed.
2. Wipe the moisture on the outer surface of the inner pot and place the inner pot into the cooker. Make sure that there are no foreign objects on the bottom where the cooker is in contact with the inner pot, and then close the lid.
3. Plug the power cord into an available power outlet (220-240V~ 50/60Hz).
4. Press the "MENU" key, select the "SOUP" function (default is 2:00; press "+" "-" to adjust in the range of 1:30-4:00) and then press the "START" key to start cooking.
5. The cooker beeps, a rotating light symbol appears on the nixie tube, and the cooker starts cooking.
6. After cooking is completed, the cooker will beep and automatically enter the keep-warm mode.
7. When opening the lid, be careful to avoid escaping steam.
8. After all the soup or food has been removed, unplug the power cord of the cooker.




## NOTE

1. The "+" "-" keys support short pressing (the step is 0:10) and continuous pressing (the step is 0:10).
2. The amount of ingredients cooked must not exceed the maximum water level of the inner pot (Congee).
3. Do not leave the soup or food in the appliance to keep it warm for more than 12 hours.

## STEW

1. Add ingredients to the inner pot and add appropriate water as needed.
2. Wipe the moisture on the outer surface of the inner pot and place the inner pot into the cooker. Make sure that there are no foreign objects on the bottom where the cooker is in contact with the inner pot, and then close the lid.
3. Plug the power cord into an available power outlet (220-240V~ 50/60Hz).
4. Press the "MENU" key, select the "STEW" function (default is 2:00; press "+" "-" to adjust in the range of 0:30-2:00) and then press the "START" key to start cooking.
5. The cooker beeps, a rotating light symbol appears on the nixie tube, and the cooker starts cooking.
6. After cooking is completed, the cooker will beep and automatically enter the keep-warm mode.
7. When opening the lid, be careful to avoid escaping steam.
8. After all the food has been removed, unplug the power cord of the cooker.




## NOTE

1. The "+" "-" keys support short pressing (the step is 0:10) and continuous pressing (the step is 0:10).
2. The amount of ingredients cooked must not exceed the maximum water level of the inner pot (Congee).
3. Do not leave the food in the appliance to keep it warm for more than 12 hours.

## QUICK RICE

1. Using the included measuring cup, add the uncooked rice to be cooked into the inner pot.
2. Wash the rice, remove excess starch, and pour away the water; repeat this at least 2 times until the rice washing water becomes
3. Add appropriate amount of water according to the amount of uncooked rice to be cooked (refer to the water level of Jasmine Rice in the inner pot).
4. Wipe the moisture on the outer surface of the inner pot and place the inner pot into the cooker. Make sure that there are no foreign objects on the bottom where the cooker is in contact with the inner pot, and then close the lid.
5. Plug the power cord into an available power outlet (220-240V~ 50/60Hz).
6. Simply press the “QUICK RICE” key to start cooking.
7. The cooker beeps, a rotating light symbol appears on the nixie tube, and the cooker starts cooking.
8. After cooking is completed, the cooker will beep and automatically enter the keep-warm mode.
9. Open the lid and stir the rice using the included rice spatula to expel any remaining moisture and make the rice more perfect.
10. After taking out all the rice, unplug the power cord of the cooker.




### ● NOTE

1. The amount of rice and water used for cooking must not exceed the maximum water level of the inner pot.
2. Users can also adjust the ratio of rice to water for cooking according to their own needs.
3. Do not leave rice in the appliance to keep it warm for more than 12 hours.

## WHITE RICE

1. Using the included measuring cup, add the uncooked rice to be cooked into the inner pot.
2. Wash the rice, remove excess starch, and pour away the water; repeat this at least 2 times until the rice washing water becomes
3. Add appropriate amount of water according to the amount of uncooked rice to be cooked (refer to the water level of White Rice in the inner pot).
4. Wipe the moisture on the outer surface of the inner pot and place the inner pot into the cooker. Make sure that there are no foreign objects on the bottom where the cooker is in contact with the inner pot, and then close the lid.
5. Plug the power cord into an available power outlet (220-240V- 50/60Hz).
6. Simply press the “WHITE RICE” key to start cooking.
7. The cooker beeps, a rotating light symbol appears on the nixie tube, and the cooker starts cooking.
8. After cooking is completed, the cooker will beep and automatically enter the keep-warm mode.
9. Open the lid and stir the rice using the included rice spatula to expel any remaining moisture and make the rice more perfect.
10. After taking out all the rice, unplug the power cord of the cooker.



### NOTE

1. The amount of rice and water used for cooking must not exceed the maximum water level of the inner pot.
2. Users can also adjust the ratio of rice to water for cooking according to their own needs.
3. Do not leave rice in the appliance to keep it warm for more than 12 hours.

## **DELAY START**

### **JASMINE RICE, BROWN RICE, MIXED RICE, CRISPY RICE, CONGEE, STEAM, SOUP**

1. Using the included measuring cup, add the uncooked rice to be cooked into the inner pot.
2. Wash the rice, remove excess starch, and pour away the water; repeat this at least 2 times until the rice washing water becomes
3. Add appropriate amount of water according to the amount of uncooked rice to be cooked.
4. Wipe the moisture on the outer surface of the inner pot and place the inner pot into the cooker. Make sure that there are no foreign objects on the bottom where the cooker is in contact with the inner pot, and then close the lid.
5. Plug the power cord into an available power outlet (220-240V~ 50/60Hz).
6. Press the "MENU" key to select the function that requires scheduled cooking, such as "JASMINE RICE".
7. Press the "DELAY START" key, the nixie tube displays the default delay time.
8. Press the "DELAY START" or "+" "-" keys to adjust the required delay time. Taking the delay for 8 hours as an example, the cooker will complete cooking after 8 hours.
9. Press the "START" key to start cooking, the cooker will sound a prompt, and the delay time will start counting down.
10. After cooking is completed, the cooker will beep and automatically enter the keep-warm mode.
11. Open the lid and stir the rice using the included rice spatula to expel any remaining moisture and make the rice more perfect.
12. After taking out all the rice, unplug the power cord of the cooker.

### **QUICK RICE, WHITE RICE**

1. Using the included measuring cup, add the uncooked rice to be cooked into the inner pot.
2. Wash the rice, remove excess starch, and pour away the water; repeat this at least 2 times until the rice washing water becomes
3. Add appropriate amount of water according to the amount of uncooked rice to be cooked.
4. Wipe the moisture on the outer surface of the inner pot and place the inner pot into the cooker. Make sure that there are no foreign objects on the bottom where the cooker is in contact with the inner pot, and then close the lid.
5. Plug the power cord into an available power outlet (220-240V~ 50/60Hz).
6. Press the "DELAY START" key, the nixie tube displays the default delay time.
7. Press the "DELAY START" or "+" "-" keys to adjust the required delay time. Taking the delay for 8 hours as an example, the cooker will complete cooking after 8 hours.
8. Press the "QUICK RICE" or "WHITE RICE" key to start cooking, the cooker will sound a prompt, and the delay time will start counting down.
9. After cooking is completed, the cooker will beep and automatically enter the keep-warm mode.
10. Open the lid and stir the rice using the included rice spatula to expel any remaining moisture and make the rice more perfect.
11. After taking out all the rice, unplug the power cord of the cooker.

## NOTE

1. STEW and KEEP WARM do not support Delay Start.  
The delay time refers to the cooking end time. Taking the delay for 8 hours as an example, cooking will be completed after 8 hours.

It is recommended that the delay time should not exceed 12 hours, or the rice may have a peculiar smell.

1. The “DELAY START”, “+” “-” keys support short pressing (the step is 0:10) and continuous pressing (the step is 1:00).
2. When the delay time is less than the preset heating time of this function, cooking will start heating; if the delay heating time of JASMINE RICE is 1:00, heating will start when the delay countdown reaches 1:00.
3. Please refer to the table below for the delay heating time of different functions:

Function	Delay heating time
JASMINE RICE	1:00
BROWN RICE	1:30
MIXED RICE	1:20
CRISPY RICE	1:10
CONGEE	Set cooking time
STEAM	Set cooking time +0:15
SOUP	Set cooking time
QUICK RICE	0:50
WHITE RICE	0:55

## KEEP WARM/CANCEL

### KEEP WARM

- After cooking, the cooker will automatically enter the keep warm state.
- In the non-cooking state, press the “KEEP WARM/CANCEL” key to automatically enter the keep-warm state.

### CANCEL


- During the function setting process, if you need to switch or cancel the current function, you can press the “KEEP WARM/CANCEL” key and then select it again.
- Within 32 seconds of starting cooking, if you need to switch or cancel the current function, press the “KEEP WARM/CANCEL” key and then select again.
- After 32 seconds, if you need to switch or cancel the current function, you need to press the “KEEP WARM/CANCEL” key twice within 3 seconds and then select again.



**NOTE**

1. [0h] means the keep-warm time is less than 1 hour, [1h] will be displayed after 1 hour, [2h] will be displayed after 2 hours, and so on.
2. The cooker can keep warm for up to 24 hours.
3. In order to maintain the taste of food, the maximum keep-warm time is recommended to be no more than 5 hours.
4. During the keep-warm process, the cooker will heat intermittently to keep the food in the pot above 65°C.

**The Use of Water Level Lines**



Rice: When adding water, for BROWN RICE, MIXED RICE, CRISPY RICE, QUICK RICE, the water level line depends on the water level line scale of the JASMINE RICE.

Maximum rice amount	Minimum rice amount
5.5 cups	1 cup

CONGEE: Refer to the CONGEE water line when adding water.  
Cooking CONGEE.

Maximum rice amount	Minimum rice amount
1 cup	0.5 cup

Steam: When steaming, please add water according to the inner pot steaming Cooking water line, too much water will cause water overflowing when it is boiling, and too little water will cause the food to become undercooked.

# CLEANING AND MAINTENANCE


Make sure that the product is not powered on during cleaning and maintenance.

## Remove The Cover

Tip: For the first time use, you can simply clean it according to the following steps. Subsequent cleaning can be carried out regularly according to the usage.

### 1 Remove the cover

Press the red button to remove the cover (the cover will tilt forward)



### NOTE


The cover sealing ring can't be disassembled separately. Do not pull the sealing ring hard to avoid damage.

## Remove Steam Valve

After cleaning, please install the sealing ring in place before closing the cover

Push the lock and pull it out upwards

Rotate in the unlocking direction to disassemble



## Clean The Cooker Body /inner Pot/steamer

### 1 Clean the cooker body

Wipe with a clean soft cloth




### NOTE

After cleaning the inside of the cooker body, be sure to dry it and avoid turning on the power when there is water.

### 2 Clean the inner pot/steamer

Soak in clean water for 10 minutes to allow the remaining rice to fully absorb water and then rinse.



### NOTE

Do not use steel wool to clean the inner pot to avoid scratching the inner pot coating.

### 3 Dry

After cleaning, dry the inner pot and steamer



# TROUBLESHOOTING

Operation of your appliance can lead to errors and malfunctions. The following tables contain possible causes and notes for resolving an error message or malfunction. It is recommended to read the tables carefully below in order to save your time and money that may cost for calling to the service center.


Abnormal situation	Possible reasons	Solutions
Too soft, too hard, too thick, too thin, not cooked, burnt rice, rice soup overflowing and insufficient boiling	<ul style="list-style-type: none"> <li>• Not add water according to the water level line</li> <li>• Wrong selection of the function</li> <li>• There is foreign matter on coil plate</li> <li>• No proper installation of the steam valve</li> <li>• Deformation of inner pot</li> </ul>	<ul style="list-style-type: none"> <li>• Add water according to the water level line</li> <li>• Select the corresponding function</li> <li>• Remove foreign matters on the heating plate (coil plate) and cook again</li> <li>• Steam valve is installed in place</li> <li>• Contact customer replace the inner pot</li> </ul>
Peculiar smell, discolouration and dry during heat preservation	<ul style="list-style-type: none"> <li>• The sealing ring and the edge of the inner pot are mixed with foreign matters</li> <li>• Product air leakage</li> <li>• Too long warm preservation time</li> </ul>	<ul style="list-style-type: none"> <li>• Remove the foreign objects</li> <li>• Contact customer service center to replace the sealing ring</li> <li>• It is recommended that the heat preservation shall be within 5 hours</li> </ul>
Abnormal noise in the working process	<ul style="list-style-type: none"> <li>• Water on the inner pot has not been dried</li> <li>• On and off sound in the operation</li> </ul>	<ul style="list-style-type: none"> <li>• Dry the water on the inner pot before using</li> <li>• Normal phenomenon</li> </ul>

When an error code appears on the display, you can check and handle it according to the following list. If the problem cannot be solved, please contact after-sales service.

Indicator status	Error display	Possible cause	Solution
Always on	E1	Bottom sensor open circuit	If the fault persists after unplugging the power plug and turning it on again, please send it to local after-sales service for repair
	E2	Bottom sensor short circuit	
	E3	IGBT sensor open circuit	
	E4	IGBT sensor short circuit	
	E5	Upper cover sensor open circuit	
	E6	Upper cover sensor short circuit	
	EU	Communication reception failure	
Flashing	EU	Communication transmission failure	
Always on	E2	IGBT overheating protection	Check whether the air inlet and outlet are blocked and whether the fan rotates smoothly. After troubleshooting, if the fault persists after powering on again, send it to after-sales service for repair.
Always on	E4	No pot protection	Check to make sure to put the inner pot in and then turn on the power again. If it still reports a fault, send it to after-sales service for repair
Always on	E6	Stepper motor damaged	If the fault persists after unplugging the power plug and turning it on again, please send it to local after-sales service for repair
	E7	Solenoid valve failure	
Flashing	E8	Electrode failure	Clean the cover plate and electrode probe and then power on again. If the failure still occurs, send it to after-sales service for repair.

To determine the cause of abnormal display, please entrust local dealers or service outlets for repair or installation.

# TRADEMARKS, COPYRIGHTS AND LEGAL STATEMENT

 Midea logo, word marks, trade name, trade dress and all versions thereof are valuable assets of Midea Group and/or its affiliates (“Midea”), to which Midea owns trademarks, copyrights and other intellectual property rights, and all goodwill derived from using any part of an Midea trademark. Use of Midea trademark for commercial purposes without the prior written consent of Midea may constitute trademark infringement or unfair competition in violation of relevant laws.

This manual is created by Midea and Midea reserves all copyrights thereof. No entity or individual may use, duplicate, modify, distribute in whole or in part this manual, or bundle or sell with other products without the prior written consent of Midea.

All the described functions and instructions were up to date at the time of printing this manual. However, the actual product may vary due to improved functions and designs.

# DATA PROTECTION NOTICE

For the provision of the services agreed with the customer, we agree to comply without restriction with all stipulations of applicable data protection law, in line with agreed countries within which services to the customer will be delivered, as well as, where applicable, the EU General Data Protection Regulation (GDPR).

Generally, our data processing is to fulfil our obligation under contract with you and for product safety reasons, to safeguard your rights in connection with warranty and product registration questions. In some cases, but only if appropriate data protection is ensured, personal data might be transferred to recipients located outside of the European Economic Area.

Further information are provided on request. You can contact our Data Protection Officer via **MideaDPO@midea.com**. To exercise your rights such as right to object your personal data being processed for direct marketing purposes, please contact us via **MideaDPO@midea.com**. To find further information, please follow the QR Code.









*make yourself at home*



[www.midea.com](http://www.midea.com)

© Midea 2022 all rights reserved